


Sailing

Tracking Mounting Manual

AT THE HEART OF PERFORMANCE

Laser, Laser Radial,
RS:X, 470, 49er, 49FX,
Finn, Nacra 17,
2.4mR, Sonar, Skud 18



Equipment 2 pieces

1. Socket plate
Used for attaching the Module.
This plate will stay on your boat for the entire duration of the regatta.
This is the piece that **identifies you** and your boat.
2. Swiss Timing Tracking Module
Must be securely clicked on to your Socket.
Collected every day before races start in exchange for your (and your crew's) accreditation.
Return to same location within the protest time limit.
The tracking module calculates your position and transmits.




Socket Information

2 way to mount this on your boat:

1. Using Velcro Tape and a safety line.
2. Using cable ties.



Please mount your socket so that the number is on the outside and readable.



Swiss Timing Tracking Module Information

Start sliding from half way along the Socket as shown in picture 2.

Slide module onto Socket and make sure you hear the click. The 'click' means the Module is locked to the Socket. Please check that it does not comes off.





RS:X Men & Women

Place: inside the sail pocket.

Mounting material: Socket will have a rope. This rope is to be securely attached to the loop inside the sail pocket.

Antenna pointing down.

Keep the socket clear of the batten.



Laser & Laser Radial

Place: On the mast just below the height of the boom.

Mounting material: Two cable ties.

Antenna pointing up.



Please mount your socket so that the number is on the outside and readable.

470 M & W

Place : of transom bar, above rudder.

Mounting material : Two cable ties.



Please mount your socket so that the number is on the outside and readable.


Finn

Place: On the foredeck. Just before mast and after the hatch.

Mounting material: Velcro tape and safety line.
Antenna to the bow of the boat.
Ensure you have the safety line attached!

It is acceptable to remove the module from the socket when being towed; don't forget to secure the module when you reach the race Area.

Please mount your socket so that the number is on the outside and readable.



49er and 49erFX


Place: On top the top side of the boom as pictured (must be clear of vang bar).

Mounting material: 2 cable ties.
Antenna to the stern of the boat.

Please mount your socket so that the number is on the outside and readable.



Nacra 17



Place: On underside of the boom as pictured (must be clear of vange).
Mounting material: 2 cable ties.
Antenna to the bow of the boat. Do not bend antenna.

Please mount your socket so that the number is on the outside and readable.



2.4 mR Class

Place: On the spreader, next to the mast. Either starboard or backboard side.

Mounting material: Cable ties & Socket. Please do not attach socket to close to mast. GPS Device will be slide on that way.

Please mount your socket so that the number is on the outside and readable.




Sonar Class

Place: On stern deck, just to the portside of the backstay fitting.

Mounting material: Velcro tape and safety line to backstay fitting.

Antenna to the portside.

Ensure safety line is clear of all control lines.



Please mount your socket so that the number is on the outside and readable.

Skud 18

Place: Backboard wall of the cockpit, as far to the stern as possible.

Mounting material: Velcro tape and safety line shackle saddle on deck.

Antenna upright and must be above the deck .

Please mount your socket so that the number is on the outside and readable.

