

International Tornado Class

The following interpretation of the 2008 Tornado Class Rules are in response to a question from the International Tornado Class Association; the following interpretation has been issued:



Question:

Rule F.3.4 FITTINGS

(a) Mandatory:

3) **gennaker** halyard guide

Can the spinnaker halyard guide, be replaced with a fitting that is not supplied by the mast builder?

Answer

No – the only permitted spinnaker halyard guide fitting is that supplied as standard by the mast manufacturer.

ISAF Secretariat
31 July 2008