


# INTERNATIONAL MELGES 24 CLASS RULES

2009



# **INDEX**

PAR	Γ I – ADMINISTRATION	C.9	Rig	12
Section A – General		C.10	Sails	15
<b>A.</b> 1	Language 4	<b>C</b> .11	Boat Handling Rules	15
A.2	Abbreviations 4	Section	on D– Hull	
A.3	Authorities 4	D.1	Parts	16
A.4	Administration of the Class 4	D.2	General	16
A.5	ISAF Rules 4	D.3	Hull Shell	17
A.6	Class Rules Variations 5	D.4	Deck	18
A.7	Class Rules Amendments 5	D.5	Bulkheads & Internal	18
A.8	Class Rules Interpretation 5	D.6	Assembled Hull	18
A.9	International Class Fee and	Section E – Hull Appendages		
	ISAF Building Plaque 5	E.1	Parts	19
A.10	Sail Numbers 5	E.2	General	
<b>A.11</b>	Hull Certification 5	E.3	Keel	
A.12	Initial Hull Certification 5	E.4	Rudder Blade, Rudder Stock	
A.13	Validity of Certificate 6	Д. 1	and Tiller	21
	Hull Re-Certification 6	Section	on F – Rig	
A.15	Retention of Certification	F.1	Parts	21
	Documentation 6	F.2	General	22
	on B – Boat Eligibility	F.3	Mast	22
B.1	Class Rules and Certification 6	F.4	Boom	24
B.3	Class Association Membership . 6	F.5	Bowsprit	24
DADT	THE DECLIDEMENTS AND	F.6	Standing Rigging	24
PART II – REQUIREMENTS AND LIMITATIONS		F.7	Running Rigging	25
	on C – Conditions for Racing	Section G - Sails		
C.1	General 7	<b>G</b> .1	Parts	26
C.2	Crew 7	G.2	General	26
	Personal Equipment 7	G.3	Mainsail	26
C.4	Advertising 8	G.4	Headsail	28
C.5	Portable Equipment 8	G.5	Spinnaker	29
C.6	Boat			
C.7	Hull 10	PART	Γ III – APPENDICES	
C.8	Hull Appendages 12		Measurement diagrams	31

# INTRODUCTION

The intention of these International Melges 24 Class rules is to ensure the boats are as identical as possible in construction, hull shape, weight, weight distribution, equipment, rigging and sail plan. Therefore, coring, drilling out, rebuilding, replacement of material, grinding or relocating standard equipment, fairing interior or exterior parts of hull, hull appendages or rig that improves moments of inertia, or changes the standard shapes or contours shall be prohibited.

International Melges 24 hulls, hull appendages, rigs and sails are measurement and manufacturing controlled.

International Melges 24 hulls shall only be manufactured by Melges Performance Sailboats in the US, Devoti Sailing S.R.O in Europe and Northshore Yachting Services Pty Ltd in Australia – in the class rules referred to as licensed builders.

International Melges 24, hull appendages shall only be manufactured by Devoti Sailing S.R.O – in the class rules referred to as the licensed builder.

International Melges 24, rigs shall only be manufactured by Southern Spars – in the class rules referred to as the licensed builder.

International Melges 24 Sails may be manufactured by optional sailmakers.

Equipment is required to comply with the International Melges 24 Building Specifications and is subject to an ISAF approved manufacturing control system.

International Melges 24 hulls, hull appendages, rigs and sails may, after having left the manufacturer, only be altered to the extent permitted in Section C of the class rules.

Owners and crews should be aware that compliance with rules in Section C is NOT checked as part of the certification process.

Rules regulating the use of equipment during a race are contained in Section C of these class rules, in ERS Part I and in the Racing Rules of Sailing.

This introduction only provides an informal background and the International Melges 24 Class Rules proper begin on the next page.

The class permits IHC for Section D hulls, Section E hull appendages, Section F masts and for Section G sails. Although the builders may operate IHC for sections D, E and F they are also checked by random independent inspection by official measurers.

# PLEASE REMEMBER: IF THESE RULES DO NOT SAY YOU CAN, THEN YOU CANNOT!

# PART I – ADMINISTRATION

# Section A – General

# A.1 LANGUAGE

- A.1.1 The official language of the class is English and in case of dispute over translation the English text shall prevail.
- A.1.2 The word "shall" is mandatory and the word "may" is permissive.

# A.2 ABBREVIATIONS

- A.2.1 ISAF International Sailing Federation
  - MNA ISAF Member National Authority
  - ICA International Melges 24 Class Association
  - NCA National Class Association
  - ERS Equipment Rules of Sailing
  - RRS Racing Rules of Sailing

# A.3 AUTHORITIES

- A.3.1 The international authority of the class is the ISAF which shall co-operate with the ICA in all matters concerning these **class rules**.
- A.3.2 Notwithstanding anything contained herein, the **certification authority** has the authority to withdraw a **certificate** and shall do so on the request of the ISAF.
- A.3.3 The copyright holder shall be Reichel & Pugh Yacht Design Inc.

# A.4 ADMINISTRATION OF THE CLASS

- A.4.1 ISAF has delegated its administrative functions of the class to MNAs. The MNA may delegate part or all of its functions, as stated in these **class rules**, to an NCA.
- A.4.2 In countries where there is no MNA, or the MNA does not wish to administrate the class, its administrative functions as stated in these **class rules** shall be carried out by the ICA which may delegate the administration to an NCA.
- A.4.3 Neither the ISAF, an MNA, the ICA, an NCA, the copyright holder or an official measurer is under any legal responsibility in respect of these class rules.
- A.4.4 A measurer shall seek approval from the ICA, but shall only be an official measurer when recognised or appointed by a MNA.

# A.5 ISAF RULES

- A.5.1 These **class rules** shall be read in conjunction with the ERS.
- A.5.2 Except where used in headings, when a term is printed in "**bold**" the definition in the ERS applies and when a term is printed in "*italics*" the definition in the RRS applies.

# A.6 CLASS RULES VARIATIONS

A.6.1 At Class Events – see RRS 89.1.d) – ISAF Regulation 26.5(f) applies. At all other events RRS 87 applies.

# A.7 CLASS RULES AMENDMENTS

A.7.1 Amendments to these **class rules** are subject to the approval of the ISAF in accordance with the ISAF Regulations.

# A.8 CLASS RULES INTERPRETATION

A.8.1 Interpretation of **class rules** shall be made in accordance with the ISAF Regulations.

# A.9 INTERNATIONAL CLASS FEE AND ISAF BUILDING PLAQUE

- A.9.1 The licensed hull builder shall pay the International Class Fee.
- A.9.2 The Copyright Holder shall, after having received the International Class Fee for the hull, send the ISAF Building Plaque and a measurement form to the licensed hull builder.

# A.10 SAIL NUMBERS

A.10.1 Sail numbers shall correspond to the number on the International Class Building Fee Plaque.

# A.11 HULL CERTIFICATION

- A.11.1 A **certificate** shall record the following information:
  - (a) Class
  - (b) Certification authority
  - (c) Sail number
  - (d) Owner
  - (e) Craft identification number
  - (f) Builder/Manufacturers details
  - (g) Date of issue of initial certificate
  - (h) Date of issue of certificate
  - (i) Keel weight
  - (j) Keel serial number
  - (k) Complete boat weight
  - (1) Corrector weights

# A.12 INITIAL HULL CERTIFICATION

- A.12.1 For a **certificate** to be issued to hull not previously **certified**:
  - (a) **Certification control** shall be carried out by the **official measurer** who shall complete the appropriate documentation.
  - (b) The documentation and **certification** fee, if required, shall be sent to the **certification authority**.

(c) Upon receipt of a satisfactorily completed documentation and **certification** fee, if required, the **certification authority** may issue a **certificate**.

# A.13 VALIDITY OF CERTIFICATE

- A.13.1 A hull **certificate** becomes invalid upon:
  - (a) the change to any items recorded on the hull **certificate** as required under A.11.
  - (b) withdrawal by the certification authority,
  - (c) the issue of a new **certificate**,

# A.14 HULL RE-CERTIFICATION

- A.14.1 The **certification authority** may issue a **certificate** to a previously certified **hull**:
  - (a) when it is invalidated under A.13.1(a) and/or after receipt of the old **certificate**, and **certification** fee if required.
  - (b) when it is invalidated under A.13.1 (b), at its discretion.
  - (c) in other cases, by application of the procedure in A.12.

# A.15 RETENTION OF CERTIFICATION DOCUMENTATION

- A.15.1 The **certification authority** shall:
  - (a) retain the original documentation upon which the current **certificate** is based.
  - (b) upon request, transfer this documentation to the new **certification authority** if the hull is exported.

# **Section B – Boat Eligibility**

For a **boat** to be eligible for *racing*, it shall comply with the rules in this section.

# **B.1** CLASS RULES AND CERTIFICATION

- B.1.1 The boat shall:
  - (a) be in compliance with the class rules.
  - (b) have a valid hull **certificate**.
  - (c) have valid **certification marks** as required. The International Class building fee plaque shall be permanently displayed on the starboard side, aft face of the transom.

# **B.2** CLASS ASSOCIATION MEMBERSHIP

- B.2.1 The owner and helmsman shall be a current member of their NCA or, where there is no NCA in his country, a member of the ICA or and NCA nominated by the ICA
- B.2.2 Sails shall carry a Class Association Sail Label.

# PART II – REQUIREMENTS AND LIMITATIONS

The **crew** and the **boat** shall comply with the rules in Part II when *racing*. In case of conflict Section C shall prevail.

The rules in Part II are closed class rules. Certification control and equipment inspection shall be carried out in accordance with the ERS except where varied in this Part.

# **Section C – Conditions for Racing**

# C.1 GENERAL

# C.1.1 RULES

- (a) RRS 49.2 is changed in that the tension may be modified as per C.7.2 (12).
- (b) RRS 42.3(c) is modified to allow the spinnaker sheet to be played without restriction.
- (c) The ERS Part I Use of Equipment shall apply.

# C.2 CREW

# C.2.1 LIMITATIONS

- (a) The **crew** shall consist of a minimum of 3 persons.
- (b) No **crew** member shall be substituted during an event of less than 7 consecutive days, unless prior written permission has been granted by the race committee or Jury.

# C.2.2 WEIGHTS

minimum maximum

Re-weighing shall only take place if a valid protest shows the pre-race weights were false.

# C.3 PERSONAL EQUIPMENT

# C.3.1 MANDATORY

(a) The boat shall be equipped with **personal buoyancy** for each crew member to the minimum standard EN 393: 1995 (CE 50 Newtons), or USCG Type III, or AUS PFD 1.

# C.4 ADVERTISING

# C.4.1 LIMITATIONS

Advertising shall only be displayed in accordance with the ISAF Advertising Code except as modified here. It shall apply to all Melges 24 Class racing.

C.4.2 The following restrictions on advertising shall apply. The number of advertisers is unrestricted.

### HULL:

- (i) The area 2.4m long, aft of any Bow numbers shall be kept free for event advertising.
- (ii) The remaining area may carry advertising chosen by the boat to a total maximum length of 3m.
- (iii) The cockpit may carry advertising chosen by the boat and is unrestricted in length
- (iv) The deck may carry advertising chosen by the boat of not more than one advertiser and of unrestricted area. The advert may connect to the advert on the hull side.

**HULL APPENDAGES**: Advertising chosen by the boat may be displayed on the keel fin and bulb, rudder and tiller. The area is unrestricted and each item may display a different advertiser.

**MAST:** Advertising chosen by the boat may be displayed on the mast. The maximum length of the adverts shall be 3.2m. Different advertisers may be on each side of the mast.

**BOOM:** Advertising chosen by the boat may be displayed on the boom. The length is unrestricted. Different advertisers may be on each side of the boom.

# **SAILS:**

SPINNAKER: Unrestricted.

**JIB**: No advertising allowed.

**MAINSAIL**: At all times the advertising shall be below and clearly separated from the national letters and sail numbers. Not more than one advertiser chosen by the boat may be displayed on each side of the Mainsail. The advert shall have a maximum length of 2.6m and a maximum height of 1.3m.

# C.5 PORTABLE EQUIPMENT

# C.5.1 FOR USE

- (a) MANDATORY
  - (1) One manual bilge pump
  - (2) One bucket of not less than 9ltr capacity, with a lanyard of minimum 1 metre.
  - (3) One anchor and chain combined of not less than 5 kg in weight and with the anchor of not less than 3.1kg
  - (4) One anchor line of not less than 40 m of line of not less than 8 mm in diameter
  - (5) Two main companionway hatches
  - (6) The engine tray carried under the engine.
- (b) OPTIONAL
  - (1) Electronic or mechanical timing devices

- (2) Navigation lights, tactical and navigational instruments and their associated power sources.
- (3) Mooring lines
- (4) Cool/ice box
- (5) Bunk cushions and portable toilet. Cushions shall be on the bunks and the toilet stowed under the companionway step.
- (6) Protective bag for companionway hatches
- (7) The 6 hatches from the cabin 'V' berth/settees

# C.5.2 NOT FOR USE

# (a) MANDATORY

- (1) One functioning outboard engine and bracket:
  - 2 stroke minimum nominal power 2kw (3hp)
  - 4 stroke minimum nominal power 1.46kw (2hp)
  - Minimum engine weight empty of fuel 12.5kg
- (2) When not in use, engine and outboard bracket shall be stowed in the engine berth below the main cockpit.
- (3) The boat shall depart the dockside with the engine tank full and suitable separate container with a minimum 3lts of fuel.

# C.6 BOAT

# C.6.1 WEIGHT

minimum maximum

The weight shall be taken excluding **sails** - engine, bracket and fuel can – anchor chain and warp – manual bilge pump – bucket and lanyard - and all portable equipment as listed in C.5.1(b) except that the permanently fixed parts of timing and navigational/tactical equipment (e.g. display heads and sensors) may be include in the weight. All batteries and power sources shall be removed.

# C.6.2 CORRECTOR WEIGHTS

- (a) **Corrector weights** of lead shall be equally divided fore and aft and permanently fastened in the locations on the diagram in section H when the **boat** weight is less than the minimum requirement.
- (b) The total weight of such **corrector weights** shall not exceed 20 kg. See also rules A.13 and B.1.1.
- (c) The aft corrector weight on the fore side of the bulkhead may be split equally part and starboard.
- (d) Corrector weights shall not be reduced more than once every 12 months.

# C.7 HULL

# C.7.1 MODIFICATIONS. MAINTENANCE AND REPAIR

(a) The moulded gel coat below the waterline and for not more than 30mm above the waterline may be lightly abraded back to allow for the

- application and adhesion of anti-fouling products, for those boats to be left afloat. The abrasion of the gel coat shall be the minimum needed to ensure adhesion of the coating and shall not involve fairing of any sort. The application of paint and epoxy treatments, whilst allowed, shall be completed under the supervision of a measurer.
- (b) Normal propriety polishes may be used on the hull if in compliance with RRS 53.
- (c) Sanding is prohibited on all hull, deck and internal structures unless repair of superficial damage is required. If there is any doubt to the interpretation of "superficial damage", a ruling shall be sought from a measurer or the technical committee before repair work commences and the boat offered for re-measurement on completion.
- (d) If the hull requires to be painted to repair a damaged gelcoat, the process shall be reported to a measurer and the boat offered for **re-certification** on completion
- (e) Fairing the keel box area or keel box Delrins is prohibited. The Delrin may be bedded in on optional material and adjusted to fit flush with the underside of the hull.
- (f) A metal plate may be used to reinforce the transom behind the fittings for boats needing repair in this area. The plate shall not exceed 4mm in thickness.

# C.7.2 FITTINGS

- (a) USE
  - (1) Additional location holes may be drilled in the jib tracks to position the jib car.
  - (2) The manufacturer or brand of the blocks and winches is optional. The sheave height from fixing point and sheave diameter shall not exceed the following dimensions.

	minimum	maximum.
Jib clew blocks. Diameter:	26mm.	30mm.
Jib car blocks. Diameter:	42mm.	46mm.
Jib car blocks: Top surface of jib car to		
bearing surface of Sheave	50mm.	54mm.
Jib ratchet blocks. Diameter:	74mm.	78mm.
Mainsheet track block. Diameter:	54mm.	58mm.
Mainsheet boom blocks. Diameter:	54mm.	58mm.
Mainsheet ratchet block. Diameter:	54mm.	78mm.
Spinnaker turning blocks. Diameter:	54mm.	78mm
Spinnaker deck ratchet blocks. Dia:	74mm.	78mm.
Bowsprit end block. Diameter:	Optional	
All control line blocks. Diameter:	Optional	
Hiking line block. Diameter:	Optional.	

The spinnaker tack line cleat may be changed to a stopper.

- (3) The position of the winches or deck ratchet blocks for the spinnaker and jib and their associated cleats is optional. There shall be not more than two cleats per side for the jib
- (4) The spinnaker turning blocks may be either free running or ratchet blocks.
- (5) The traveller and backstay cleats may be placed within a box measuring 1900mm and 2150mm aft of the MB and between the lower edge of the deck non skid and a line 180mm below this edge on the cockpit moulding.
- (6) A block may be added above the traveller cleat, or the traveller may be rigged in such a way as to be able to use a windward sheeting system of optional design, except that the mainsheet shall still be attached to the traveller car in the standard way.
- (7) The mainsheet swivel cleat may be fitted either forward or aft of the mainsheet track. Alternatively the mainsheet swivel cleat may be removed and the cleat mounted on the lower block. The upper two single blocks may be combined into a double block.
- (8) The rear gate line across the transom shall be closed whilst racing. It shall be in one continuous piece, fixed using shackles of optional design. The deflection at the centre when measured from a straight line between the attachment points shall not be more than 75mm.
- (9) The hiking line shall be attached at the deck fitting forward and to the designed eye on the pulpit aft. The method of attachment is optional.
- (10) Padding may be fitted to the hiking lines. The line may be either a continuous line with added padding or lines (with or without padding) linked by webbing sections. The method of joining the hiking line and the webbing is optional. The webbing shall be a minimum of 50mm wide.
- (11) From the aft stanchion, the hiking line may be led down and through either a block or a shackle attached to the spinnaker turning block deck eye, or through the deck eye itself, and up to the stern pulpit.
- (12) When pushing down hard on the hiking lines at the mid point between the two centre stanchions, no part of the hiking line including padding etc shall touch the deck.
- (13) Additional foot chocks may be fitted to the cockpit floor, including moulded foot chocks and on the engine hatch cover. The shape is optional. They shall not exceed 100mm in height above the horizontal surface of the cockpit floor.
- (14) A proprietary hatch not exceeding 220mm in internal diameter may be fitted to the cockpit floor to allow access to the rudder and backstay fittings. A water tight bung may be fitted in the transom as per D.6.2.
- (15) Fairings of any material may be used over blocks and fittings on deck to assist in the free running of sheets and control lines.
- (16) Storage bags may be attached to the cockpit moulding.

- (17) Protective covers may cover the shrouds, vang and recess for the furler drum.
- (18) Non slip tape or similar non slip material may be added to the decks, cockpit floor and gunwale edge as necessary.

# C.8 HULL APPENDAGES

# C.8.1 MODIFICATIONS, MAINTENANCE AND REPAIR

(a) Normal propriety polishes may be used on the **hull appendages** if in compliance with RRS 53.

# C.8.2 KEEL

(a) DIMENSIONS with keel fully lowered:

minimum maximum

# Hull datum point to intersection of hull and

fin trailing edge, around hull on centreline ....... 3482 mm .. 3494 mm

# Hull datum point to intersection of fin trailing

edge and top of keel bulb, straight line ...... 3784 mm .. 3823 mm

Underside of hull in a straight line to top of

keel bulb at the trailing edge of the keel ............ 1195 mm .. 1215 mm

# (b) USE

- (1) The **keel** shall be fixed down using the supplied locking strap.
- (2) The **keel** shall only be retracted when not racing, using the Melges designed lifting crane

# C.8.3 RUDDER

(a) DIMENSIONS

minimum maximum

# (b) USE

- (1) The rudder head between gudgeons shall be parallel to the transom, +/- 2mm.
- (2) Shims may be fitted between the rudder and tiller to ensure a good fit.

# C.9 RIG

# C.9.1 MODIFICATIONS, MAINTENANCE AND REPAIR

(a) Routine maintenance such as cleaning, polishing, repair of minor abrasions and the replacement of fittings is permitted without re-measurement and re-certification

# C.9.2 LIMITATIONS

(a) Only one set of **spars** and standing **rigging** shall be used during an event of less than 7 consecutive days, except when a item has been lost or damaged beyond repair.

# C.9.3 MAST

- (a) USE
  - (1) The mast may be fitted with a protective gaiter below the gooseneck.
  - (2) The spreader connector bar shall not be modified or changed during a regatta.
  - (3) The mast as supplied and assembled in accordance with the building specification shall be stepped on the standard mast step. No wedges or similar devices shall be used to control or alter the rake or bend characteristics of the rig, except that permanently attached shims may be used to correct misalignment.
  - (4) The **mast** shall be fitted with a securely fixed sail track stop as supplied by the licensed builders.

# C.9.4 BOOM

(a) DIMENSIONS

- (b) USE
  - (1) The intersection of the aft edge of the mast **spar** and the top of the boom **spar**, each extended as necessary, shall not be below the upper edge of the mast **lower limit mark** when the boom **spar** is at 90° to the mast **spar**.
  - (2) A shackle, block or similar device may be fitted to the underside of the boom to help guide the spinnaker halyard.
  - (3) The **boom** shall be fitted with a securely fixed sail track stop as supplied by the licensed builders.
  - (4) The boom may be fitted with a security line including fittings.

# C.9.5 RETRACTING BOWSPRIT

- (a) USE
  - (1) A batten or similar may be fitted to the end or the bowsprit. It shall extend not more than 300mm from the outer end.
  - (2) The retraction line is optional. The bowsprit may be retracted by a knot in the tack line.
  - (3) A second cleat may be added in the cockpit/deck for the tack line.
  - (4) The bowsprit shall be capable of being retracted to have its forward end level with or aft of the forward side of the stem.
  - (5) The bowsprit shall be retracted when the spinnaker is not flying
  - (6) Tape or other materials may be added around the bowsprit to help ensure a watertight seal.

# (b) DIMENSIONS

minimum maximum

Centre of "u" bolt to foreside of stem – straight line ...... ... 1400 mm

# C.9.6 STANDING RIGGING

- (a) USE
  - (1) The shrouds and forestay may be attached and adjusted by turnbuckles/bottlescrews/pin plates of optional design. Lock plates may be fitted.
  - (2) Rigging links and rigging screws may be adjusted while racing, but at the turnbuckles/bottlescrews only. Remote adjustment of any type is prohibited.

# C.9.7 RUNNING RIGGING

- (a) USE
  - (1) The main halyard shall be secured below deck. It shall use a sheet stopper and/or cleats mounted on the starboard side of the compression tube. It may be tensioned by a purchase of not more than 4:1 (including a cleat if required) and one hook or fastening. It shall not lead to the deck nor be able to be operated from above deck.
  - (2) The jib shall be hoisted by one of 3 options:
    - (a) The s/s wire jib halyard connected to the jib luff wire, through the original jib sheave and which shall be secured to the high field lever.

OR

- (b) An HMPE or similar (e.g. Spectra) halyard, running inside the zip luff. The design of the system is optional.
- OR (c) An HMPE or similar halyard led through the original jib sheave in the mast and secured to a purchase system below deck. The design of the system is optional but the purchase system shall be entirely below deck.
- System (b) may be used with either forestay system and System (c) shall be used with a fixed forestay.
- An existing mast may be retro fitted with the fixed forestay using the official parts available from the licensed builders.
- (3) The complete boom vang as supplied may be fitted with the cleat at either mast of boom end.
- (4) The spinnaker sheet may have a single gybe line spliced into them at the clew.
- (5) The use of shock cord is unrestricted except that it may not be used on the rear gate line or to retract the bowsprit in any way.
- (6) No lines shall lead below deck other than the main halyard, jib halyard, jib furling line and the bow sprit launch and recovery line with tackle.
- (7) Additions to or subtractions of purchase, to the mainsheet system, spinnaker sheet system, main cunningham, boom vang, main outhaul, jib sheet system, traveller controls, bowsprit launch systems, backstay or reefing systems shall not be permitted. The

cunningham may be led through the mainsail eye/block and tied off on the gooseneck fitting.

# C.10 SAILS

# C.10.1 MODIFICATIONS, MAINTENANCE AND REPAIR

- (a) Sails shall not be altered in any way except as permitted by these class rules.
- (b) Routine maintenance such as cleaning and minor repairs is permitted without re-measurement and re-**certification**.

# C.10.2 LIMITATIONS

- (a) Not more than 1 mainsail, 1 headsail and 2 spinnakers shall be carried aboard.
- (b) Not more than 1 mainsail, 1 headsail and 2 spinnakers shall be presented for registration and used during an event of less than 8 consecutive days, except when a **sail** has been lost or damaged beyond repair.
- (c) Sails shall not be changed or substituted whilst underway or away from the dockside.

# C.10.3 MAINSAIL

- (b) USE
  - (1) The **sail** shall be hoisted on a halyard. The arrangement shall permit hoisting and lowering of the **sail** at sea.
  - (2) The highest visible point of the **sail**, projected at 90° to the mast **spar**, shall not be set above the lower edge of the mast **upper limit mark**. The intersection of the **leech** and the top of the boom **spar**, each extended as necessary, shall not be behind the fore side of the boom **outer limit mark**.
  - (3) The **Luff** bolt rope shall be in the **spar** grooves.
  - (4) The mainsail shall be attached to the boom only at the **clew**

# C.10.4 JIB

- (a) USE
  - (1) The jib shall be capable of being furled around the forestay, from the cockpit, using the designed furling system.

# C.10.5 SPINNAKER

(a) IDENTIFICATION

The sail numbers and national letters are optional.

- (b) USE
  - (1) The spinnaker may be stowed in a bag in the companionway hatch. The design of this bag is optional.

# C.11 BOAT HANDLING RULES

C.11.1. Approaching a windward mark without the spinnaker set, the bowsprit shall not be extended until the bow of the boat has passed the mark. If for a wind shift, or any other reason, the spinnaker is flown on a 'windward ' leg, then the

- bowsprit shall be fully extended and the spinnaker set before the boat reaches the two hull length circle at a mark.
- C.11.2. When the bowsprit is extended the boat shall be in the process of a continuous hoist, or flying or dropping the spinnaker.
- C.11.3. The bowsprit shall be retracted at the first reasonable opportunity after rounding the leeward mark.
- C.11.4. The skipper or crew shall not hike out by sitting facing outboard over the spinnaker turning block. The skipper/helmsman shall not sit in any way that projects the body below the waist beyond the sheerline, nor shall they use any fitting or device with which to hike from any part of the body below the waist.
- C.11.5. When tacking, or gybing, standing up and hanging or pushing/leaning on the shrouds, mast or any other item to promote the manoeuvre shall be prohibited.
- C.11.6. RRS 42.3 (c) is modified to allow the spinnaker sheet to be trimmed without restrictions in all conditions
- C.11.7 When hiking, the crews shall either sit facing outboard in such a way that at least a part of the back of the thigh/buttocks is in contact with the deck or gunwale edge, kneel on the aft corner of the side deck or, stand with at least one foot on the cockpit floor.

# **Section D – Hull**

# D.1 PARTS

# D.1.1 MANDATORY

- (a) Hull shell
- (b) Deck
- (c) Internal mouldings and bulkheads
- (d) Engine stowage tray
- (e) Mast compression post

# D.2 GENERAL

# D.2.1 RULES

(a) The **hull** shall comply with the **class rules** in force at the time of initial **certification.** 

# D.2.2 CERTIFICATION

See Rule A.12. The **official measurer**, the ICA, the MNA or the ISAF may use destructive testing to determine compliance with construction rules.

# D.2.3 MODIFICATIONS, MAINTENANCE AND REPAIR

- (a) The hull shell, deck, bulkheads, and cockpit shall not be altered in any way except as permitted by these **class rules**.
- (b) Holes not bigger than necessary for the installation of through core knot meters and depth sounders may be made in the hull shell.
- (c) Routine maintenance such as painting and polishing and minor repairs is permitted without re-measurement and re-**certification**.

(d) If any hull moulding is substantially altered or repaired in any other way than described in D.2.3(c), its measurement certificate shall cease to be valid until the relevant parts of the hull have been re-measured and the measurement certificate re-validated by the MNA.

# D.2.4 DEFINITIONS

# (a) HULL DATUM POINT

The **hull datum point** is the intersection, on the centreplane of the **hull** between the underside of the shell and the transom upstand, each extended as necessary.

(b) The fore and aft position of deck fittings shall be measured from the forward side of a straight measurement beam (MB) minimum 2400mm in length, (not less that 100mm wide), laid across the boat on the deck and against the aft face of the cabin. Measurements shall be taken parallel to the fore and aft centreline of the yacht. The beam may have cut outs to fit around any instruments fitted in the aft face of the cabin.

# D.2.5 IDENTIFICATION

- (a) The hull shall carry the ISAF Plaque permanently placed on the starboard side, aft face of the transom.
- (b) All boats shall carry an official serial number which shall include the sail number/ ISAF plaque number, moulded into or securely fixed to the starboard side, aft face of the transom. This number shall be either; part of a national requirement such as European Standard ISO 10087: 1996 for those relevant countries, or, where the builder does not have to conform to a national requirement, or does not intended for his boats to be imported into Europe, the number shall be from a series formulated by Melges Performance Sailboats. The sail number shall be clearly identifiable on the transom.

# D.2.6 BUILDERS

- (a) The hull shall built by a builder licensed by Copyright Holder.
- (b) All moulds shall be approved by the Copyright Holder and ISAF.
- (c) The licensed builder shall, at his own expense, correct or replace any hull that does not comply with the class rules as a result of an omission or error by the builder, if the hull is submitted for fundamental measurement within twelve months of purchase.

# D.3 HULL SHELL

# D.3.1 MATERIALS

(a) The hull shell shall be built from glass reinforced materials within the builder's license.

# D.3.2 CONSTRUCTION

(a) The hull shell shall be built from approved moulds in accordance with the licensed building specifications.

# D.4 DECK

# D.4.1 MATERIALS

(a) The deck shall be built from glass reinforced materials within the builder's license.

# D.4.2 CONSTRUCTION

(a) The deck shall be built from approved moulds in accordance with the licensed building specifications.

# D.5 BULKHEADS AND INTERNAL MOULDINGS

### D.5.1 MATERIALS

(a) The bulkheads and internal structures shall be built from glass reinforced materials within the builder's license.

# D.5.2 CONSTRUCTION

(a) The bulkheads and internal structures shall be built from approved moulds in accordance with the licensed building specifications.

# D.6 ASSEMBLED HULL

# D.6.1 FITTINGS

# (a) MANDATORY

Fittings shall be positioned in accordance with the building specification and not modified unless stated within these rules:

- (1) Jib furling drum and forestay attachment
- (2) Shroud plates
- (3) Headsail tracks. The centreline of the tracks shall lie alongside the cabin sides on the level deck on the inboard edge of the non-slip moulding. There shall be one track to port and one to starboard.
- (4) Mainsheet track with one traveller
- (5) Mast step. The forward face shall be measured in a straight line from the aft face of the furler drum recess at deck level
- (6) Aft spinnaker turning block deck plates
- (7) Stanchions. There shall be two stanchions and one hiking line fitted to each side of the boat.
- (8) Stern pulpit and aft gate line.
- (9) Hiking line deck attachments to the building specification or equivalent strength

# (b) OPTIONAL

- (1) Bow pulpit as per building specification
- (2) One drain plug in the transom.

# D.6.2 DIMENSIONS

minimum maximum

Horizontal distance from aft face of furler drum recess

Longitudinal distance forward of MB as defined
in D.2.4(b) to centre of shroud plates
Transverse distance between centres of shroud plate at leading face of shroud
plate hole centreline. Equal across hull centreline 1725 mm 1750 mm
Headsail track length
Longitudinal distance forward of MB as defined
in D.2.4(b) to forward end of tracks 510 mm 530 mm
Measured by jig across the centreline of the hull
total distance between centrelines of track forward 978 mm 1000 mm
Measured by jig across the centreline of the hull
total distance between centrelines of track aft 1012 mm 1032 mm
Mainsheet track aft of MB
Position of aft spinnaker turning block deck plates
centre of fitting aft of MB
Position of aft spinnaker turning block deck plates
distance from outboard edge of deck moulding 15 mm 25 mm
Longitudinal distance from MB
to fixed forward end of hiking line on deck 2470 mm 2500 mm
Underside of hole in stanchion above deck
Optional transom drain plug – internal diameter

# **Section E – Hull Appendages**

# E.1 PARTS

# E.1.1 MANDATORY

- (a) Keel
- (b) Rudder

# E.2 GENERAL

# E.2.1 RULES

(a) **Hull appendages** shall comply with the **class rules** in force at the time of **certification**.

# E.2.2 MODIFICATIONS, MAINTENANCE AND REPAIR

- (a) Hull appendages shall not be altered in any way except as permitted by these class rules.
- (b) Routine maintenance such as cleaning, polishing and the repair of superficial damage and abrasions is permitted without re-measurement and re-certification. If there is doubt of the interpretation of "superficial damage" a ruling shall be sought from an **official measurer** or the technical committee before work commences. On completion the **appendage** shall be **re-certified.**

# E.2.3 CERTIFICATION

(a) The official measurer shall certify hull appendages.

- (b) An MNA may appoint one or more persons at a manufacturer to measure and **certify hull appendages** produced by that manufacturer in accordance with the ISAF In-house Certification Guidelines.
- (c) The official templates shall be those registered with and approved by ISAF.

# E.2.4 MANUFACTURERS

- (a) The **hull appendages** shall be made by manufacturers licensed by the copyright holder and ISAF.
- (b) The manufacturer shall, at his own expense, correct or replace any **hull appendage** that does not comply with the class rules as a result of an omission or error by the builder, if the spar is submitted for fundamental measurement within twelve months of purchase.

# E.3 KEEL

# E.3.1 RULES

- (a) The keel shall have a unique serial number on the part of the keel which remains inside the boat.
- (b) The keel fin and keel bulb shall at no time be transferred from one hull to another without full **re-certification** to current class rules.

# E.3.2 MATERIALS

- (a) The **keel** fin shall be of carbon fibre reinforced materials specified in the building specification.
- (b) The **keel** bulb shall be of lead.
- (c) The **keel** bulb shall be covered as per the building specifications.

# E.3.3 CONSTRUCTION

(a) The **keel** shall be manufactured from a moulds approved by the Copyright holder and ISAF.

# E.3.4 FITTINGS

- (a) MANDATORY
- (1) The forward edge of the keel shall be fitted with a kelp cutter to the Melges design. The slot in which the cutter operates shall not be filled or covered.
- (2) The keel fin shall be fitted with a removable stainless steel ring used to lift the keel with the Melges keel crane.

# E.3.5 DIMENSIONS

The keel fin and keel bulb shall conform to official templates.

# E.3.6 WEIGHTS

	minimum	maximum
Combined keel fin and keel bulb	300 kg	313 kg

# E.4 RUDDER BLADE, RUDDER STOCK AND TILLER

# E.4.1 RULES

(a) The **rudder** blade shall have a unique serial number on the side of the **rudder** head.

# E.4.2 MATERIALS

- (a) The **rudder** blade shall be of carbon fibre reinforced materials specified in the building specification.
- (c) The tiller shall be of fibre reinforced materials specified in the building specification
- (d) The tiller extension material is optional.

# E.4.3 CONSTRUCTION

(a) The **rudder** blade shall be manufactured in a mould approved by the Copyright holder and ISAF.

# E.4.4 FITTINGS

- (a) MANDATORY
  - (1) The rudder shall be attached to the transom by means of 2 pintles on the rudder and 2 fittings, with loose pin or pins, on the transom. These fittings shall comply with official drawings
- (b) OPTIONAL
  - (1) Tiller extension

# E.4.5 DIMENSIONS

The rudder shall conform to official templates.

minimum maximum

. .

# E.4.6 WEIGHTS

min	nimum	maximum
Rudder including gudgeons and fixing bolts	7.5 kg	
Tiller inc extension and bolt to fix tiller to rudder	1.8 kg	

# Section F - Rig

# F.1 PARTS

# F.1.1 MANDATORY

- (a) Mast
- (b) Boom
- (c) Standing **rigging**
- (d) Running rigging
- (e) Bowsprit

# F.2 GENERAL

# F.2.1 RULES

- (a) The **spars** and their fittings shall comply with the **class rules** in force at the time of **certification** of the **spar**.
- (b) The standing and running **rigging** shall comply with the **class rules**.

# F.2.2 MODIFICATIONS, MAINTENANCE AND REPAIR

- (a) **Spars** shall not be altered in any way except as permitted by these **class** rules.
- (b) Routine maintenance such as cleaning, polishing, repair of minor abrasions and the replacement of fittings is permitted without re-measurement and re-certification.

# F.2.3 CERTIFICATION

- (a) The official measurer shall certify spars.
- (b) No **certification** of standing and running **rigging** is required.
- (c) An MNA may appoint one or more persons at the **spar** builders to measure and **certify spars** produced by that manufacturer in accordance with the ISAF In-house Certification Guidelines.

# F.2.4 DEFINITIONS

(a) MAST DATUM POINT

The **mast datum point** is the top face of the mast foot casting as per the diagram in section H.

# F.2.5 MANUFACTURER

- (a) The **spar** builder shall be licensed by the Copyright holder.
- (b) The manufacturer shall, at his own expense, correct or replace any spar that does not comply with the class rules as a result of an omission or error by the builder, if the spar is submitted for fundamental measurement within twelve months of purchase.
- (c) The manufacturer of standing and running rigging is optional.

# F.3 MAST

# F.3.1 MATERIALS

(a) The **spar** shall be of carbon fibre reinforced materials specified within the builders licence.

# F.3.2 CONSTRUCTION

- (a) The **spar** shall be built from moulds approved by the Copyright Holder and ISAF and to the approved building specification.
- (b) The **spar** shall be fitted out to the requirements of the building specification.
- (c) From the 1st November 2008, the mast shall be constructed with a fixed forestay system as per the builder's specification. An existing mast may be retro fitted with the fixed forestay using the official parts available from the licensed builders.

# F.3.3 FITTINGS

(a) The following are permitted

Mast head crane, backstay batten, wind vane, sheaves and sheave boxes, tangs and T ball sockets, one pair of spreaders, spreader attachments, gooseneck, boom vang fitting, halyard cleats and line stowage cleats, supplied mast foot, compass bracket, mast alignment shims, protective cloth sleeves and items as permitted or prescribed by other applicable *rules*.

- (b) Spreaders, including the spreader bar, to the approved design shall only be supplied by the licensed builder. The spreaders shall be connected with the spreader bar only.
- (c) The mast head crane shall be fitted with a sail batten connected to the backstay. The length and specification of the batten is optional and it may be fitted with a ring, block or similar.

# F.3.4 DIMENSIONS

minimum maximum
Mast spar cross section above mast foot;
<b>fore-and-aft</b>
<b>transverse</b>
Mast spar cross section at upper point;
<b>fore-and-aft</b>
<b>transverse</b>
Mast limit mark width
Start of taper above mast datum point
Constant section to this point
Lower point height
Upper point height
<b>Forestay height</b>
Jib halyard height
Jib halyard sheave bearing surface diameter
Main <b>shroud height</b>
Lower <b>shroud height</b>
Backstay crane:
Top aft corner vertically above <b>upper point</b>
From aft face of mast
<b>Spinnaker hoist height</b>
<b>Spinnaker</b> halyard sheave bearing surface diameter 30 mm 40 mm
Samondon:
Spreader;
length
height
aft side of mast to taut line on aft side of shrouds 230 mm 260 mm

# F.3.5 WEIGHTS

# F.4 BOOM

# F.4.1 MATERIALS

- (a) The **spar** shall be of aluminium alloy.
- (b) Permitted surface finish shall be anodised.

# F.4.2 CONSTRUCTION

- (a) The **spar** extrusion shall be approved by ISAF.
- (b) The **spar** shall be built and fitted out to the requirements of the building specification.

# F.4.3 FITTINGS

(a) The following are permitted

Clew outhaul and fittings, sheaves and sheave boxes, blocks, cleats, hooks, attachment fittings, spinnaker stowage fittings, reefing fittings and items as permitted or prescribed by other applicable *rules*.

# F.5 BOWSPRIT

# F.5.1 MANUFACTURER

- (a) The builders shall be licensed by the Copyright Holder.
- (b) Builders shall only build bowsprits from moulds approved by the Copyright Holder and ISAF.

# F.5.2 MATERIALS

(a) The **spar** shall be of carbon fibre.

# F.5.3 CONSTRUCTION

(a) The construction shall be as per specified in the builders license.

# F.5.4 FITTINGS

(b) (a) The following are permitted: Sheaves and sheave boxes, blocks, 'U' bolts, sheet catching batten, blanking off caps, tape or other materials for sealing against the rubber seal when pole is retracted and items as permitted or prescribed by other applicable *rules*.

# F.6 STANDING RIGGING

# F.6.1 MATERIALS

- (a) The standing **rigging** shall be of stainless steel cable.
- (b) The backstay material is optional.

# F.6.2 FITTINGS

(a) The following are permitted:

Turnbuckles/bottlescrews, pin plates, tangs, swages, swage eyes, shackles, shroud lock plates.

# F.6.3 DIMENSIONS

	minimum maximum
Forestay diameter	4.7 mm 5.1 mm
Mains shroud diameter	4.7 mm 5.1 mm
Lower shroud diameter	4.7 mm 5.1 mm
Backstay diameter stainless steel	3.0 mm
Backstay breaking strain if not s/s wire	950 kg

# F.7 RUNNING RIGGING

# F.7.1 MATERIALS

- (a) Materials are optional for the main and spinnaker halyards and for the jib halyard with the fixed forestay system.
- (b) The jib halyard for the original system shall be 7x19 stainless steel wire.
- (c) The material and diameter for sheets and control lines is optional unless specified.

# F.7.2 CONSTRUCTION

- (a) MANDATORY
  - (1) Mainsail halyard may be tapered
  - (2) Mainsail sheet
  - (3) Headsail halyard
  - (4) Headsail sheets lead through blocks on the jib tracks
  - (5) Spinnaker halyard may be tapered
  - (6) Spinnaker sheets may be tapered
  - (7) Bowsprit setting and retraction lines
  - (8) Backstay control system
  - (9) Mainsail Cunningham line
  - (10) Mainsail outhaul system in the boom
  - (11) Mainsheet traveller control system
  - (12) Headsail Cunningham system
  - (13) Headsail furling line
- (b) OPTIONAL
  - (1) Reefing lines

# F.7.3 FITTINGS

- (a) MANDATORY
  - (1) Boom Vang

# F.7.4 DIMENSIONS

	minimum	maximum
(a) Hiking line 7x10 coated s/s wire diameter	3.1 mm	
(b) Hiking line HMPE diameter	4.5 mm	
(c) Jib halyard of 7x19 s/s cable diameter	4.7 mm	5.1 mm
(d) Main halyard diameter	4.7 mm	

- (f) Jib halyard for fixed forestay system diameter ......2.5 mm

# **Section G – Sails**

# G.1 PARTS

# G.1.1 MANDATORY

- (a) Mainsail
- (b) Headsail

# G.1.2 OPTIONAL

(a) Spinnaker

# G.2 GENERAL

# G.2.1 RULES

(a) Sails shall comply with the class rules in force at the time of certification.

# G.2.2 CERTIFICATION

- (a) The **official measurer** shall **certify** sails near the **tack** and shall sign and date the **certification mark**.
- (b) An MNA may appoint one or more persons at a sailmaker to measure and **certify sails** produced by that manufacturer in accordance with the ISAF In-house Certification Guidelines.
- (c) The **certification mark** shall be either the individually numbered class stamp issued to each **official measurer** or the marking system approved by ISAF for In House Certification (IHC) which may require a signature and date.
- (d) Each **sail** constructed after 1st January 1997 shall have permanently fixed, (with stitching), near to its **tack**, an official ICA label. No **sail** shall be accepted for its **fundamental measurement** without a sail label. The **measurer** shall sign across the label and sail to ensure that it cannot be transferred to another sail. Labels shall only be available from the ICA secretary (or treasurer) and the cost shall be fixed by the ICA in general meeting.

# G.2.3 SAILMAKER

- (a) No licence is required.
- (b) The weight in g/m<sup>2</sup> of the **body of the sail** shall be indelibly marked near the **head point** by the sailmaker together with the date and his signature or stamp.

# G.3 MAINSAIL

# G.3.1 IDENTIFICATION

(a) The class insignia shall conform to the dimensions and requirements as detailed in the diagram contained in Section H.

- (b) The word Melges shall be coloured mid to dark blue and the figures 24 shall be coloured teal green.
- (c) The class insignia shall positioned on both sides of the mainsail, between the top two **batten pockets** with the starboards side being higher.
- (d) The national letters and sail numbers shall comply with the RRS.
- (e) The national letters and sail numbers shall be positioned on both sides of the mainsail, between the second and third **batten pockets**.

# G.3.2 MATERIALS

- (a) The **ply** fibres shall consist of polyester, aramids or HMPE.
- (b) **Stiffening** shall consist of:
  - (1) Cornerboards: plastic or aluminium
  - (2) Battens: wood, GRP, FRP.
- (c) **Sail reinforcement** shall consist of polyester, aramids, HMPE or GRP.
- N.B. Aramid is marketed under trade names such as Kevlar and Twaron and HMPE under trade names such as Spectra and Dyneema.

# G.3.3 CONSTRUCTION

- (a) The construction shall be: soft sail, single ply sail.
- (b) The **body of the sail** shall consist of **woven** and/or **laminated ply** throughout.
- (c) The sail shall have 4 **batten pockets** in the **leech**. The upper two shall be full length and extend from **leech** to **luff**. The centreline of the 4 **batten pockets** shall divide the **leech** (total distance from **aft head point** to **clew**) into five equal parts, +/- 100mm.
- (d) One reef position may be fitted.
- (e) Windows are permitted below half width.
- (c) The following are permitted: Stitching, glues, webbing, woven and PTFE tapes, bolt ropes, corner eyes, corner rings, headboard with fixings, Cunningham eye or pulley, Velcro or other fastenings, reefing points, batten pocket patches, batten pocket elastic, batten pocket end caps, batten retaining devices, mast and boom slides, leech line with cleat, windows, tell tales, sail shape indicator stripes and items as permitted or prescribed by other applicable *rules*.
- (g) For mainsails manufactured after the 1st December 2007, the weight of the complete sail shall comply with the weight listed in class rule G.3.4.
  - a) The sail shall be weighed with fixed fittings but excluding battens and tensioners.
  - b) The mainsail shall not include any special devices, which are designed to, or might perform the task of corrector weights.
  - c) Fittings shall be the normal size fittings for a sail of this size and available from standard suppliers.
  - d) If fittings or construction are designed in any way to circumvent this rule, measurement shall be refused.

# G.3.4 DIMENSIONS

Where no limit(s) for a particular dimension is given then the item is not controlled and need not be measured

minimum m	naximum
Leech length	9590 mm
Foot median	9200 mm
Half width	2700 mm
Three-quarter width	680 mm
Top width	175 mm
Reef point above tack and clew points	000 mm
Weight of complete sail	
Window area	$1.0 \text{ m}^2$
Batten pocket length:	
Lower two pockets:	
inside 1	780 mm

# G.4 HEADSAIL

# G.4.1 MATERIALS

- (a) The **ply** fibres shall consist of polyester, aramids or HMPE.
- (b) **Stiffening** shall consist of:
  - (1) Cornerboards: plastic or aluminium
  - (2) Battens: optional material
- (c) **Sail reinforcement** shall consist of polyester, aramids, HMPE or GRP.

# G.4.2 CONSTRUCTION

- (a) The construction shall be: soft sail, single ply sail.
- (b) The **body of the sail** shall consist of the same **woven** and/or **laminated ply** throughout.
- (c) The headsail may have 3 **battens** in the **leech**. The battens shall have one end placed on the leech. The battens shall not prevent the **sail** from furling completely.
- (d) The **leech** shall not extend beyond a straight line from the aft **head point** to the **clew point**.
- (e) Windows are permitted below half width.
- (f) The jib luff wire if fitted shall be 7x19 or 7x7 or 1x19 and may be coated or non-coated wire.
- (g) The following are permitted: Stitching, glues, webbing, tapes, **luff** wire, corner eyes, corner rings, Velcro or press studs, battens, batten pockets, batten pocket elastic, **batten pocket patches**, batten pocket end caps, Cunningham eye or block with cleat, leech line with cleat, foot line with cleat, **windows**, two blocks for sheets, zip for sleeve **luff**, tell tales, sail shape indicator stripes and items as permitted or prescribed by other applicable *rules*.

- (h) For headsails manufactured after the 1st January 2006, the weight of the complete sail shall comply with the weight listed in class rule G.4.3.
  - a) The sail shall be weighed complete with fixed fittings and jib sheet blocks but excluding battens and jib luff wire.
  - b) The headsail shall not include any special devices, which are designed to, or might perform the task of corrector weights.
  - c) Fittings shall be the normal size fittings for a sail of this size and available from standard suppliers.
  - d) If fittings or construction are designed in any way to circumvent this rule, measurement shall be refused.
- (i) Headsails manufactured and **certified** after the 1st November 2008, shall be fitted with a zip luff designed to enclose the forestay, and any jib halyard and purchase system used. The zip shall not be used as a device to alter the sail shape

# G.4.3 DIMENSIONS

Where no limit(s) for a particular dimension is given then the item is not controlled and need not be measured

minimum maximum
<b>Luff length</b>
<b>Leech length</b>
<b>Foot length</b>
<b>Top width</b>
<b>Windows</b> area
Weight of complete sail
Batten length
Batten width
Batten pocket centreline position on leech from clew 750 mm 6000 mm
Forward most point of batten from <b>leech</b>
<b>Luff</b> wire diameter
Luff wire. Length between bearing surfaces

# G.5 SPINNAKER

# G.5.1 MATERIALS

- (a) The **ply** fibres shall consist of non polyester.
- (b) Sail reinforcement shall consist of:

**Primary reinforcement** – material optional **Secondary reinforcement** – non polyester

# G.5.2 CONSTRUCTION

- (a) The construction shall be: soft sail, single ply sail.
- (b) The **body of the sail** shall consist of **woven ply** throughout.
- (c) Windows are permitted below half width.
- (d) National letters and sail numbers are optional.

(e) The following are permitted: Stitching, glues, webbing, woven tapes, corner eyes, corner rings, **windows**, leech line and cleat, luff line and cleat, foot line and cleat, sail shape indicator strips, tell tales and items as permitted or prescribed by other applicable *rules*.

# G.5.3 DIMENSIONS

Where no limit(s) for a particular dimension is given then the item is not controlled and need not be measured

	minimum	maximum
Luff length	11285 mm	11585 mm
Leech length	10000 mm	11078 mm
Foot length	6000 mm	6300 mm
Foot Median		12000 mm
Half width		5860 mm
Three-quarter width		3700 mm
Weight of ply of the body of the sail	40 g/m <sup>2</sup>	
Windows	-	0.75m²


# PART III - APPENDICES


The rules in Part III are **closed class rules**. Measurement shall be carried out in accordance with the ERS except where varied in this Part.


# **Section H**

# **H.1**

# Mast datum point











Illustration regarding dimension C corrected 5<sup>th</sup> February 1998

Note: On all measurements (excluding angles) relating to the class insignia there is a tolerance of +/- 5mm.



Effective: 1<sup>st</sup> December 2008

Previous issues: 4th Jan 2008

23<sup>rd</sup> May 2007

1st March 2006

© ISAF 2009